



Generic CR80 Cleaning Card - Pre-Saturated With IPA

Packing : 25 Pre-saturated Cleaning Cards Per Box
Nominal Size Dimension : 54 X 86 X 0.711 mm
Part Number : TPCC-CR80

Features & Benefits

- Economical Costs to maintain your Card Readers in Routine Maintenance to prevent misread or reading failure.
- Less machine failures due to effective dirt removal.
- Easy handling
- Isopropyl Alcohol Cleaner will safely clean , remove dust, dirty stain, and leave no Residue on the surface.
- Refer to MSDS TPCC-CR80

Applications

IPA pre-saturated CR80 Cleaning Card is an alternative Cleaner for preventive maintenance of ATM Machines, POS Terminal, Magnetic Stripe Swipe Card Readers, Smart Card Readers, Hotel Door Lock Readers, Petroleum Gas Station, Slot Machines, Vending Machines, ID Card Printers.

Characteristics

Card Readers require preventative maintenance for keeping the Magnetic Heads clean and debris free from contamination build up. It cleans and revitalizes the transport rubber rollers, rollers path guide.

Pre-saturated Cleaning cards are a cost effective way to maintain your card readers and increase the service life of the magnetic heads.

Technical Specification

The substrate material is PVC and laminate on both sides with Blend Spunlace Cleaning Fabrics and it is pre-saturated with IPA solution and pouched in polyester laminated aluminum foil to provide excellent moisture vapor barrier properties.

- Card Material : Spunlace/Plastic Core/Spunlace
- Card dimensions : 54 x 86 x 0.96 mm
- Card Dimension : 2.125 X 3.375 X 0.028 (in Inches) Thickness Tolerance +/- 0.002"
53.975 X 85.7 X 0.711 (in mm) Thickness Tolerance +/- 0.051mm
- Corner Radius : 4 Sides.
- Paper Pouch Size : 83 X 127 (in mm)
- Solution Content : 99.9% IPA
- IPA Volume : 1.0 +/- 0.25 ml



CR80 Cleaning Card

TDS

TECHNICAL DATA SHEET

Packaging



Generic CR80 Cleaning Card

Packing : 50 Pre-saturated Cleaning Cards per Box.
Box Dimension (mm) : 130*65*90
With Printed Label.
Gross Weight (Kg) : 0.20

Carton Box : 50 Boxes per Cartons ; 2500 Cards per Carton.
Carton Dimension (mm) : 345*270*470
Cubic Volume (m3) : 0.044
Gross Weight (Kg) : 20.00

Custom HS Code : 34011990.00